



SPECTROGON

Optical filters • Coatings • Gratings

Date: 2006-04-18 09:18

Operator :

Filter specification :
Type : BP (Bandpass)

CWL = 890 +/- 20 nm
HW = 70 +/- 20 nm
Blocking : UV to 1200

Size : Ø25,4x0,5mm

Qty : pc

Spectrogon
Art.nr :
Batch nr :
Order nr :

Customer
Part nr :
P.O. nr :

Actual sample values : Data collection range : 650 to 1150 nm Diagram range : 650 to 1149 nm

CWL = 885,9 nm OK
HW = 66,9 nm 7,55 % OK
Cuton 5% = 833,9 nm
Cutoff 5% = 949,4 nm
Tmin. = 91,6 %
Tpeak = 91,64 %
Tave. = 91,64 %

Left Slope : 3,65 %
Right Slope : 4,13 %