

SPECTROGON

Optical filters • Coatings • Gratings

Date: 18-11-12

Operator:

Article:

Art no: 713

NB-3010-040 nm Ø25.4x0.5 mm

Specifications:

CWL: 3010 ±15 nm

HW: 40 ±10 nm

Tmin: 70 %

Blocking: 100 - 11000 nm (OD 3)

Measurement conditions:

Temperature: 23 °C

AOI: 0 deg

Measured values:

CWL = 3004,02 nm

HW = 34,06 nm

Cuton 5 % = 2970,62 nm

Cutoff 5 % = 3037,56 nm

HP1 = 2986,99 nm

HP2 = 3021,05 nm

Tpeak = 74,17 %

Tavg = 70,9 %

Slope 1 = 0,75 %

Slope 2 = 0,71 %

Spectrogon:

Ref:713.720.390

Calibration traceable to NIST.

Spectrogon products conform in all aspects with the RoHS Directive.

